## Morth American Truck Platforms

INSTRUCTION SHEET


ITEM REFERENCE PROCESS MATERIAL TORQUE EXISTING AS PART OF ASSEMBLY INSTRUCTIONS

REMOVE COVER 4
REMOVE AUTS (2 PER SIDE) FROM WELD STUDS 3
TO REMOVE SEAT FROM FLOOR.
REMOVE BOLI/SCREW 2 FROM LATCH ASM 1
REMOVE RUBBER BUMPER 9 FROM LATCH ASM, DISCARD.
THREAD BALL PLUNGER 1 INTO SUPPORT BRACKET
17 WITH BALL END ORIENTATED AS SHOWN.
ATTACH SUPPORT BRACKET 17 TO LATCH ASM 1
BY REINSTALLING BOLI/SCREW 2
REINSTALL LATCH ASM 11 ONTO WELD STUDS,
INSTALL BASE 3 OVER REAR WELD STUD 3.
ORIENTATE AS SHOWN, REINSTALL NUTS ON REAR WELD STUD 3.
MAKE NECESSARY ADJUSTMENTS BY ADJUSTING
BALL PLUNGER 5 AND/OR SUPPORT BASE.
TRIM RUBBER BUMPER 9 TO FIT, IF NECESSARY, AND INSTALL
TRIM/MODIFY COVER 4 AS SHOWN 5 TO
CLEAR SUPPORT BRACKET 7 ASSEMBLY INSTRUCTIONS LATCH ASM L & RH **BOLT/SCREW** -SEAT BACK WELD STUDS COVER L & RH **MODIFY TRIM BALL PLUNGER** SUPPORT BRACKET WELD NUTS (FRAME) 8 BASE 1 BUMPER SEAT CUSHION 5 Z 9 Z REMOVE THIS PORTION OF THE TRIM COVER, SEE SHEET 3 FOR TEMPLATE. LH SHOWN RH OPPOSITE **FASTENER TORQUE** GENERAL INSTRUCTION NOTES ST TRUCK SERIES S 20 - 30 Nm TILE **REAR SEAT LATCH KIT** INSTRUCTION SHEET 2 PART NO DATE SHEET **3** 01SE93 1 OF 3 15982741

North American Truck Platforms

INSTRUCTION SHEET

☐ ITEM REFERENCE ♦ PROCESS MATERIAL ♦ TORQUE ☐ EXISTING AS PART OF



 $\hat{3}$ 

15982741

PART NO

DATE

25FE94

SHEET

2 OF 3

North American Truck Platforms

INSTRUCTION SHEET

ITEM REFERENCE PROCESS MATERIAL TORQUE EXISTING AS PART OF

